


Configuring Your Hardware

- [STAR Printers - Adding a Logo](#)

STAR Printers - Adding a Logo

1. Navigate to <https://starmicronics.com/support/>
2. Enter your printer model or serial number.

Image not found or type unknown



3. Click on your printer.

Image not found or type unknown




4. Download the "StarPRNT Intelligence Software Setup EXE File"

Image not found or type unknown




5. Install the downloaded setup EXE and then open the "Printer Utility Star PRNT" that's installed.
6. Follow the printer connection wizard if shown.

Image not found or type unknown




7. Click "Logo Store"

Image not found or type unknown



8. Click "Add"

Image not found or type unknown



9. Select the logo file to use.

Tip: Tested logo size: 300px x 100px

10. Click "Store Logos"

Image not found or type unknown



11. To check how the logos look, click "Yes"

Image not found or type unknown

